


HECHT[®] 1569

made for garden



Position	Part number	Název	Name
14	H156814	Pilový list (dřevp)	Blade saw (wood)
27	H156927	Držák uhlíku	Carbon brush holder
28	H156928	Uhlík (pár)	Carbon brush (pair)
29	H156929	Rotor	Rotor
31	H156931	Stator	Stator
59	H156959	Spínač	Switch
63	H156855	Pravítko	Ruler
64	H156856	Adaptér sběrného vaku	Bag adapter