




Position	Part number	Název	Name
1-1	5072000011	Spínač kompletní	Switch assembly
43	507200043	Koš kompletní	Grassbox assembly
44	507200044	Poklice	Wheel cover
44-1	5072000441	Kolo s krytem	Wheel with cover
45	507200045	Závlačka	Pin
46	507200046	Kolo	Wheel
50	507200050	Nůž	Blade
51-1	5072000511	Unašeč	Blade holder
60	HECHT001277BX	Akumulátor 20V 2Ah	Battery 20V 2Ah
61	HECHT001278BX	Akumulátor 20V 4Ah	Battery 20V 4Ah
62	HECHT001289BX	Akumulátor 20V 6Ah	Battery 20V 6Ah
63	HECHT001277CH	Nabíječka	Charger
64	HECHT001289CH	Nabíječka na dva akumulátory	Charger for two battery