


# GRIZZLY GHS 2500 XL



pozice	objednací číslo	Description	Qt
1	LSG2505-12	Feeding inlet	1
2	GB/T3667-1997	Capacitor	1
3	GB862.1-1987	lock washer	1
4	LSG2505-11	shell	1
5	LSG2505-10	Circuit board	1
6	GB/T845-1985	apping screw	4
7		Connector	2
8		Connector	1
9	LSG2505-01	feeding barre	1
10	LSG2505-02	Switch cover	1
11		Yscrew	4
12	LSG2505-08	Water proof sleeve	1
13	LSG2505-05	ON press-button	1
14	LSG2505-06	OFF press-button	1
15	LSG2505-09	Spring	2
16	LSG2505-04	Bose of switch	1
17	GB/T845-1985	shape self tapping screw	4
18	LSG2505-07	Bolt	2
19		Switch	1
20		Switch	1
21	LSG2505-03	Switch box	1
22	LSG2505-29	Cable holde	1
23		Cable	1
24		Plug	1
25	LSG2505-29	Cable clip	1
26	GB/T845-1985	shape self tapping screw	2
27	GB/T845-1985	shape self tapping screw	4
28	LES1300-10	pothook	1
29	LSG2500-009	Stator with winding	1
30	LSG2505.01-01	End plate	1
31	GB2509-1981	Bushing	1

pozice	objednací číslo	Description	Qt
32	GB/T70.1-2000	Hexagon column head screw	4
33	GB93-1987	Washer	4
34	LSG2500-031-01	Gasket	1
35	LSG2500-031-02	Gasket	1
36	GB/T819-1985	Screw	4
37	LSG2505.01-05	Blade	1
38	72800210	Rwtainer block	1
39	LSG2505.01-04	Clip for fixing	1
40	GB/T889-1986	self-locked nut	1
41	GB/T70.1-2000	Hexagon column head screw	4
42	GB93-1987	Washer	4
43	LSG2505.05	Knob	1
44	LSG2505.01-02	Blade frame	1
45	GB2509-1981	Bushing	1
46	LSG2505-30	Swith base	1
47	LSG2505-31	Switch jumper	1
48	WE-D-09	Swith frame	1
49		Switch	1
50	LSG2500-001-02	Blade shaft	1
51	GB/T1059-1979	Flat key	1
52	LSG2500-003.06.2	2nd pin shaft	3
53	GB2509-1981	Bushing	1
54	LSG2500-003-06.3	2nd planetary gear	3
55	GB2509-1981	Bushing	3
56	LSG2500-003-05	2nd inner gear	1
57	LSG2500-003-03.1	Diaphragm plate	1
58	LSG2500-031-03	Washer	1
59	LSG2500-003-03	Bearing shaft	1
60	GB2509-1981	Bushing	1
61	LSG2500-003-02.1	1st planetary gear	1
62	GB894.1-1986	Snap ring	2

